

This program will test the USER command.

Activating the MNGUSER program.

Contents of CMDVAL and USERADR:

CMDVAL = 0x06
USERADR = 0xD49A

Writing to CMDVAL and USERADR.

Contents of CMDVAL and USERADR:

CMDVAL = 0x60
USERADR = 0x404D

The USER handler program is activated.

Calling USER

Entered USER function, value = 0x0000

Calling USER 1234

Entered USER function, value = 0x04D2

Calling USER \$1234

Entered USER function, value = 0x1234

Terminating USER \$FFFF

Entered USER function, value = 0xFFFF

Initializing CMDVAL and USERADR.

Contents of CMDVAL and USERADR:

CMDVAL = 0x06
USERADR = 0xD49A

Manage MNGUSER2 completed.

This program is now complete.